

## LEICA SMART ROVER – QUICK START

1 Survey

Highlight Job – press Return

F2 New – input name, codelist, coordinate system OSGB36(02) and set average mode – F1 STORE

F1 CONT

Select Config Set – SmartNet I-MAXv3 or similar

Select Antenna – ATX1230GG Pole

F1 CONT

Wait for @ sign to appear to right of L2 in Icon bar (connected to internet)

Press SHIFT – F3 CONEC (Successfully connected to NTRIP caster ie, SmartNet)

Wait for circular icon in top left of Icon bar to reduce in size from a large circle with internal cross to a cross (+) with a small circle in the centre of the cross

F1 OCCUPY to observe points – making sure the coordinate quality is set at centimetre quality

When finished ESC to Main Menu

4 Convert

1 Export Data from Job

Export to CF Card

Directory – GSI/Data

Select Job to Export

Select Format File (ie, DXF1200.frt) relevant to the processing software

F2 CONF to configure file extension ie, dxf

F1 CONT to convert data to relevant format

---