

Quick Guide Operating Instructions for the Topcon Automatic Level

- Mount the instrument on a roughly levelled tripod.
- Turn the levelling screws until the bubble of the circular level vial is in the centre of the circle (see pictures A & B).
- Put your hand in front of the objective lens, whilst looking through the level, and turn the telescope eyepiece until the cross-hairs are sharp & focussed (see picture C)
- Rotate the telescope until the sighting collimator is pointing at the staff (see picture D).
- Looking through the level, turn the telescope focus knob until the staff is in focus (see picture E).
- Turn the fine horizontal knob until the cross-hairs are on the staff, and take a level reading (see picture F).



Picture A



Picture B



Picture C



Picture D



Picture E



Picture F